

Part no.	Designation	A Lubrication width [mm]	B Housing width [mm]	C Space require- ment [mm]
1013100075	RB SF-SW 0075	75	114	335
1013100100	RB SF-SW 0100	100	139	360
1013100150	RB SF-SW 0150	150	189	410
1013100200	RB SF-SW 0200	200	239	460
1013100250	RB SF-SW 0250	250	289	510
1013100300	RB SF-SW 0300	300	339	560
1013100350	RB SF-SW 0350	350	389	610
1013100400	RB SF-SW 0400	400	439	660
1013100450	RB SF-SW 0450	450	489	710
1013100500	RB SF-SW 0500	500	539	760
1013100600	RB SF-SW 0600	600	639	860
1013100700	RB SF-SW 0700	700	739	960
1013100800	RB SF-SW 0800	800	839	1060
1013100900	RB SF-SW 0900	900	939	1160
1013101000	RB SF-SW 1000	1000	1039	1260
1013101100	RB SF-SW 1100	1100	1139	1360
1013101200	RB SF-SW 1200	1200	1239	1460
1013101300	RB SF-SW 1300	1300	1339	1560

Dimensions

